



C99 HATZ

OPERATING INSTRUCTIONS AND SPARE PARTS LIST

1	<u>Basic Safety Instructions</u>	5
1.1	<i>Symbols</i>	5
1.2	<i>Machine plate</i>	6
1.3	<i>Safety instructions for particular operating phases</i>	6
2	<u>General description of the C99</u>	7
2.1	<i>Short description</i>	7
2.2	<i>Layout</i>	7
2.3	<i>Technical data</i>	9
3	<u>Assembly and commissioning</u>	10
3.1	<i>Operator's handle assembly</i>	10
3.2	<i>Tool assembly</i>	10
3.3	<i>Water cooling system</i>	10
3.4	<i>Starting the machine</i>	11
4	<u>Transport and Storing</u>	12
4.1	<i>Securing for transport</i>	12
4.2	<i>Transport procedure</i>	12
4.3	<i>Long period of inactivity</i>	12
5	<u>Operating the C99</u>	13
5.1	<i>Site of work</i>	13
5.2	<i>Cutting method</i>	13
6	<u>Maintenance and service</u>	14
6.1	<i>Maintenance of the machine</i>	14
6.2	<i>Maintenance of the engine</i>	15
7	<u>Faults: causes and cures</u>	20
7.1	<i>Fault-finding procedures</i>	20
7.2	<i>Trouble-shooting guide</i>	20
7.3	<i>Customer service</i>	20

8	Appendix	22
8.1	<i>Spare parts list</i>	22
8.2	<i>Exploded part drawings</i>	24






1 Basic Safety Instructions

The C99 is exclusively designed for the cutting of floors made of asphalt, green and cured concrete (reinforced or not) as well as of industrial cement.

Uses other than the manufacturer's instructions shall be considered as contravening the regulations. The manufacturer shall not be held responsible for any resulting damage. Any risk shall be borne entirely by the user. Observing the operating instructions and compliance with inspection and servicing requirements shall also be considered as included under use in accordance with the regulations.


1.1 Symbols

Important warnings and pieces of advice are indicated on the machine using symbols. The following symbols are used on the machine:



1.2 Machine plate

Important data can be found on the following plate located on the machine:



1.3 Safety instructions for particular operating phases

Before commencing work

- Before commencing work, make yourself familiar with the working environment at the place of use. The working environment includes: obstacles in the area of work and manoeuvre, the firmness of the floor, necessary protection at the site relating to public thoroughfares and the availability of help in the event of accidents.
- Check for correct mounting of the blade regularly.
- Immediately remove damaged or badly worn blades, as they endanger the operator whilst rotating.
- Always cut with the blade guard in position.
- Only fit NORTON diamond blades to the machine! The use of other tools can damage the machine!
- Attention is drawn to the use of BS2092 safety goggles in conformity with specified Processes No.8 of the Protection of Eyes Regulation 1974, Regulation 2(2) Part 1.
- For security reasons, never leave the machine unattended, untied or unlocked.

While the engine is running

- Do not move the machine whilst the blade is running idle.
- Do not run the machine without the security guards in place.
- Apply cooling water continuously whilst cutting and in good time!

Petrol powered machines:

- Always use the fuel advised.
- In confined areas, exhaust gases should be evacuated and the job site properly aerated.
- Petrol and diesel machines, which by their nature emit toxic exhaust gases, must not be used in places prohibited by the Health at Work etc. Act 1974 or which are prohibited by Factory Inspectors or Safety Officers.
- Fuel is flammable. Before filling the tank, shut down the engine, extinguish all open flames and do not smoke. Take care that no petrol is spilled on any motor part. Always wipe up spilled fuel.

2 General description of the C99

Any modification, which could lead to a change in the original characteristics of the machine, may be done only by Saint-Gobain Abrasives S.A. who shall confirm that the machine is still in conformity with the safety regulations. Saint-Gobain Abrasives S.A. keeps the right of making technical or design modification without prior notification.

2.1 Short description


The **Floor Saw C99** you have chosen is used for small repair works in concrete and asphalt, for cutting induction loops and installing cables as well as for cutting expansion joints. It can be used for either wet or dry cutting operations.

Being of small construction, it can be transported in a car or van; the handle can be removed, reversed or retracted. The water container is also removable.

All component parts on the **C99** are assembled to a high quality standard, ensuring long life, reliability and a minimum of maintenance.

Special types of blades are available for asphalt, green concrete, cured concrete (reinforced or not) as well as for industrial cement flooring.

2.2 Layout



Made of jig welded open profile steel, the **C99** is stable but at the same time, easily transportable.

The one-piece blade guard (1) fully protects the operator and his working environment. It is firmly fixed to the main frame but can be opened by rotation to change blades.

A manually operated hand wheel mechanism (2) enables graduated depth setting. Turning the hand wheel clockwise or anti-clockwise will lower or raise the cutting blade. A depth gauge allows the operator to control precisely the depth of cut.

The handle (3) is detachable or can be reversed for easy transportation. The height is adjustable.

The pivoting frame (4), hinged on the rear axle, is supporting the engine, the blade shaft assembly, and the protecting guards. Four heavy-duty belts drive the blade.

The precisely manufactured blade shaft is fitted into two heavy-duty self-aligning pillow block bearings, including grease nipples. A four-belt taper lock pulley is fitted on one end. The shaft is reduced to 25,4mm at the other end, allowing an inner flange complete with dowel pinholes to be fixed.


The steel belt guard (5) is a sealed two piece unit. The backing plate is bolted to the mainframe of the machine and locking nuts are welded to it. The outer guard, covering the four drive belts and taper lock pulleys, is held in place by four locking bolts.

A spacer flange, 20mm in thickness and an outer flange, both with dowel pinholes, are provided. They are held with a 36mm locking nut.

The water cooling system (8) is composed of a 20 litres water tank, a water tank tap and two water nozzles located on the blade guard ensuring adequate flow of water to both sides of the cutting blade.

The pointer (9) allows the operator to make precise cut easily.

The HATZ 1B30 diesel engine (6) is connected to a speed regulation handle (7) on the right hand side of the machine. This handle is also used to shut the machine down in case of emergency. The engine is started using recoil starter. The following picture is showing the different parts of your engine that you need to know in order to use and maintain your machine correctly:



2.3 Technical data

Engine	Hatz 1B30, 7HP (5kW)
Fuel	Diesel complying with the following minimum specifications : EN590 or DIN15601 – DK or BS 2869 A1/A2 or ASTM D975 – 1D / 2D
Oil (Motor)	Oil complying with the following minimum specifications: CCMC – D4 – D5 – PD2 or API – CD – CE – CF – CG or SHPD Viscosity recommended : SAE 10W-30 (outside temperature between -5°C and 35°C)
Bore	25,4 mm
Max. blade diameter	450 mm
Max. cutting depth mm	165 mm
Flange diameter	108 mm
Blade shaft speed	2850 min ⁻¹
Driving belts	4
Water tank	20 l
Machine dimensions (length x width x height)	1160 x 512 x 990 mm in cutting configuration
Weight	107 kg
Max. operating weight	130 kg
Sound pressure level	91 dB (A) (ISO EN 11201)
Sound energy level	110 dB (A) (ISO EN 3744)

3 Assembly and commissioning

Before beginning the work with the C99, you have to assemble some parts.

3.1 Operator's handle assembly

Secure the operator's handle in a comfortable user position by using the locking nut.

3.2 Tool assembly

Only use NORTON blades with the C99.

A blade with a maximum diameter of 450 mm can be fitted. All tools used must be selected with regard to their maximum permitted cutting speed for the machine's maximum permitted rotation speed.

Before mounting a new blade, switch the machine off.

To mount a new blade, follow these steps:

- Turn the wheel until the cutting head is in the raised position.
- Loosen the screw maintaining the guard and turn the blade guard open.
- Loosen the hexagonal nut on the blade shaft, which holds the removable outer flange.
- Remove the outer flange.
- Clean the flanges and blade shaft and inspect for wear.
- Mount the blade on the shaft ensuring that direction of rotation is correct. Wrong direction of rotation blunts the blade quickly.
- Replace outer blade flange.
- Tighten hexagonal nut with spanner supplied for this purpose.
- Close the blade guard.

The blade bore must correspond exactly to the blade shaft. Cracked or damaged bore is dangerous for the operator and for the machine.

3.3 Water cooling system


Fill the water tank with clean water.

Open water-tap at blade guard (note that handle on water-tap should be in line with water-flow). Ensure that water is flowing freely in the circuit and delivered adequately to both sides of the blade, as insufficient water supply may result in premature failure of the diamond blade.


In case of frost, empty the water cooling system.

3.4 Starting the machine

Make sure the blade is raised clear up the ground before starting the machine.



Set the speed adjuster to the STOP position, then move it to the START/RUN position, by pulling the knob and stick it on the metal part. Never use starting sprays.



Pull the starting cable out by the handle until you feel a slight resistance. Let the cable run back; in this way the entire length of the starting cable can be used to start the machine. .



Grip the handle with both hands. Commence pulling the starting cable vigorously and at an increasing speed (do not jerk it violently) until the engine starts.

If after several attempts of starting the exhaust begins to emit white smoke, move the speed adjustment lever to the STOP position and pull the starting cable out slowly 5 times. Then repeat the starting procedure.

To stop the machine, set the speed adjuster knob to the STOP position, and press it until the engine cuts out.

4 Transport and Storing

Take the following measures in order to transport and store the C99 securely.

4.1 *Securing for transport*

Before transporting the machine:

- Remove the blade.
- Empty the water tank.
- Lower the handle in its fixing tube and secure it using the locking nut.
- Raise the guide-a-cut in its upright position.
- Raise the cutting head to its highest position using the hand wheel.

4.2 *Transport procedure*

The machine can be moved on a flat surface using its wheels. Use the metal hook located over the water tank to move the machine with a crane.

4.3 *Long period of inactivity*

If the machine is not going to be used for a long period, please take the following measures:

- Completely clean the machine.
- Loosen the drive belts.
- Grease the threaded shaft.
- Possibly change the motor oil.
- Empty the water system.

The storage site must be clean, dry and at a constant temperature.

5 Operating the C99

5.1 Site of work

Before you start working, please check the following points:

- Remove from the site anything, which might hinder the working procedure.
- Make sure the site is sufficiently well lit.
- Make sure you have a continual adequate view of the working area so you can intervene in the working process at any time.
- Keep other staff out of the area, so you can work securely.

5.2 Cutting method

In this section, you can find instructions to make a straight cut at the desired depth.

5.2.1 Preparing your cut

Before starting the machine,

- Draw a line on the floor over the cutting length.
- Make sure you have filled the engine tank with fuel, and the water tank with water. No petrol is supplied with the machine.
- The engine is shipped with oil. Check oil level before starting. Top up if required.
- Make sure you have mounted the correct blade as recommended by the manufacturer depending on the material to be worked, the working procedure (dry or wet cut) to be carried out, and the efficiency required.
- Make sure that the flanges securely hold the diamond blade.
- Make sure that the blade is not touching the floor before starting.
- Adjust the handle to a comfortable position.
- Roll the machine until the blade is over the line.
- Lower the guide-a-cut so it touches the line.

5.2.2 Cutting the floor

You can now start the engine.

To make your cut,

- Turn the depth hand wheel until the blade slightly touches the floor.
- Open water valve to control the amount of water required for the type of blade, using 15 to 25l/min for wet and 1-2l/min for dry cutting, dust control. Check for minimum water level regularly.
- To lower blade into the cut, turn hand wheel clockwise. Each turn of the hand wheel will raise or lower the blade by 10mm.
- Once the required depth of cut is reached, push the machine forward with steady and gentle pressure and follow the line with the pointer. The feed speed must be adjusted depending on the material being cut, and depth of cut.
- At the finish of the cut, raise the blade out of the cut by turning the hand wheel anti-clockwise, shut-off the water and switch off the engine.

6 Maintenance and service

ATTENTION: to perform maintenance on the machine, always switch it off. Always wear a face mask and safety goggles while performing the maintenance of machine.

6.1 Maintenance of the machine

To ensure a long-term quality from the cutting with the C99, please follow the maintenance plan below:

		Regular service period Perform at every indicated period →						
		After one hour of work	Begin of the day	During the changing of the tool	End of the day	Every week	After a fault	After a damage
Whole machine	Visual control (general aspect, water tightness)							
	Clean							
Flange and blade fixing devices	Clean							
Belts tension	Control							
Water hoses and nozzles	Clean							
Depth screw	Grease							
Engine housing	Clean							
Reachable nuts and screws	Tighten up							

Adjustment and replacement of the belts

After one hour of work, the belts heat and stretch. Therefore, you have to re-tension them.

To adjust the belts, firstly remove the belt guard by unscrewing the 4 nuts. Loose the 4 engine bolts and shift the engine by using the two screws on the front.

To replace the belts, move the engine completely to the front. Adjust the belts and retighten them by shifting the motor to the rear.

Always use a matched set of belts. Do not replace single belts.

Lubrication

The C99 uses life-lubricated bearings. Therefore, you don't need to lubricate them at all.

Grease the depth screw every day.

Cleaning of the machine

Your machine will last longer if you clean it thoroughly after each day of work.


6.2 Maintenance of the engine

		Regular service period Perform operating hour interval					
		→					
			Each use	First month or 25 hours	Every 250 hours	Every 500 hours	Every 1000 hours
Engine oil	Check level						
	Change						
Oil filter	Clean						
Cooling air zone	Check-Clean						
Air intake point	Check-Clean						
Water trap	Check						
Air cleaner filter	Clean						
	Change the cartridge						
Valve clearance	Check and adjust						
Fuel filter	Replace						
Exhaust mesh inlet	Clean						

Oil level check

When checking the oil level, the engine must not be running, and should stand horizontal.

- Remove any dirt in the dipstick area.
- Check oil level at the dipstick: top up if necessary as far as the max. mark.




Changing engine oil

The engine must be stopped, and should stand horizontal. Drain the engine oil when it is warm. **CAUTION!** Risk of scalding from hot oil.

Please dispose of used motor oil in a manner that is compatible with the environment. We suggest you to take used oil in a sealed container to your local recycling centre or service station for reclamation. Do not throw it in the trash, pour it on the ground or down in a drain.


- Take out the oil drain plug « 1 » and allow the oil to drain out.




- Clean the oil drain plug « 1 » and fit a new washer « 2 » before tightening. (Tightening torque : 50 Nm)
- Add engine oil until the max. mark on the dipstick.

Cleaning the oil filter

The oil filter should be cleaned at the same time as the engine oil is changed, since oil escapes when the filter is removed.




Loosen the screw « 1 » with approx. 5 rotations.



Remove the oil filter from housing.



Use an air line to blow out oil filter dirt from the inside outwards.




Check the joint washer « 1 » whether it is damaged. Replace it if necessary. Check the joint washer « 2 » whether it is damaged and correctly fitted. Replace the oil filter if necessary.

Lubricate joint washer before fitting.

Put in the oil filter and press until the limit stop.


Check whether tension springs sit close to oil filter with both ends "1" before tightening. Check the oil level and restore to max. level if required.



Checking the water trap

The intervals at which you check the water trap depend entirely on the amount of water in the fuel and the care taken when refuelling. However, you should check it at least once a week.

- Loosen the hexagonal screw "1" with approx. 3-4 rotations.
- Trap the drops which emerge in a transparent vessel. Since water has a greater specific gravity than diesel fuel, the water emerges before the diesel fuel. The two substances separate at a clearly visible line.
- As soon as diesel only emerges, retighten screw "1".





Cleaning the air cooling zone

Before cleaning, the engine must be stopped and allowed to cool down. If severely contaminated, clean the cooling fans on the cylinder and cylinder head, and also the fan blades in the flywheel. If necessary, contact your local HATZ service station.


Cleaning of the exhaust mesh inlet

Exhaust system components will naturally be hot and must not be touched while the engine is running or until it has cooled down after being stopped.

- Unscrew the hexagonal nut and remove the exhaust mesh insert.
- Remove any deposits in the mesh insert by means of a wire brush.
- Check the exhaust mesh insert for cracks or damage and, if necessary, replace with a new one.





Screw on the hexagonal nut « 1 » by approx. 1 turn.



Insert exhaust screen with hoop « 1 » into hole, then pull outwards again so that the hoop is retained.


Tighten the hexagonal nut fully.



Air cleaner maintenance

- Remove the air cleaner cover.
- Unscrew and remove knurled nut « 1 » and take off air cleaner element « 2 ».
- Clean the filter compartment and the cover. Dirt and other foreign bodies must not be allowed to enter the engine's air inlet points.

- Use compressed air to blow through the filter cartridge from the inside outwards until no further dirt emerges. The air pressure must not exceed 5 bar.
- Check the filter cartridge's gasket surface « 1 » for damage.
- Check the filter cartridge for cracks or any other type of damage to the paper filter by holding it inclined towards the light or by shining a light source through it.
- The slightest damage to the paper filter rules out it being used any longer.
- By wet or oily contamination, change the cartridge.
- Re-assemble the filter cartridge in the reverse order of work.



Checking of the valve clearance and of the fuel filter

Contact a HATZ-Service station to perform this maintenance.

7 Faults: causes and cures

7.1 Fault-finding procedures

Should any fault occur during the use of the machine, turn it off. Let only qualified staff make any intervention other than the one described in the previous section.

7.2 Trouble-shooting guide

Trouble	Possible source	Resolution
Engine fires but stops again as soon as the crank is disengaged	No oil pressure	Check the oil level
	Cylinder head temperature too high	Check cooling air passage
	Stronger fault	Contact nearest engine maintenance centre
Engine lacks power	Tank run dry	Add fuel
	Air filter restricted	Clean or replace air filter
	Speed control lever does not remain in the selected position	Prevent speed control from moving
	Stronger fault	Contact nearest engine maintenance centre
Engine stops by itself during regular operation	Tank run dry	Add fuel
	Air filter restricted	Clean or replace air filter
	No oil pressure	Check the oil level
	Stronger fault	Contact nearest engine maintenance centre

7.3 Customer service

When ordering spare parts, please mention:

- The serial number (seven digits or a letter and 6 digits).
- The code of the part.
- The exact denomination.
- The number of parts required.
- The delivery address.
- Please indicate clearly the means of transportation required such as "express" or "by air". Without specific instructions, we will forward the parts through the means which seem appropriate to us and but which is not always the quickest way.

Clear instructions will avoid problems and faulty deliveries.

If not sure, please send us the defective part.

In the case of a warranty is claim, the part must always be returned for evaluation.

Spare parts for the engine can be ordered with the manufacturer of the engine or with their dealer, which is often quicker and cheaper.

This machine has been manufactured by Saint-Gobain Abrasives S.A.

190, Bd J.F.Kennedy
L- 4930 BASCHARAGE
Grand-Duché de Luxembourg.

Tel. : 00352- 50 401-1

Fax : 00352- 50 16 33

<http://www.construction.norton.eu>

e-mail: sales.nlx@saint-gobain.com

Guarantee can be claimed and technical support obtained from your local distributor where machines, spare parts and consumables can be ordered as well:

Benelux and France:

From Saint-Gobain Abrasives
in the Grand-Duché de Luxembourg

Free telephone numbers:

Belgium : 0 800 18951

France: 0 800 90 69 03

Holland: 0 8000 22 02 70

e-mail: sales.nlx@saint-gobain.com

Germany

Saint-Gobain Abrasives GmbH

Birkenweg 45-49,

D-50389 WESSELING

Tel : (02236) 8911 0

Fax : (02236) 8911 30

e-mail: sales.ngg@saint-gobain.com

Spain

Saint-Gobain Abrasivos S.A.

Ctra Guipuzcoa km7,5

31195 BERRIOPLANO (Navarra)

Tel: 0034 948 30 3000

Fax: 0034 948 30 6042

e-mail : Comercial.sga-apa@saint-gobain.com

Hungary

Saint-Gobain Abrasives KFT.

Budafoki u. 111

H-1117 BUDAPEST

Tel: ++36 1 371 2250

Fax: ++36 1 371 2255

e-mail: nortonbp@axelero.hu

United Kingdom

Saint-Gobain Abrasives Ltd.

Doxey road

Stafford

ST 16 1EA

Tel : 0845 602 6222

Free Fax : 0800 622 385

e-mail : nortondiamonduk@saint-gobain.com

Italy

Saint-Gobain Abrasivi S.p.A.

Via per Cesano Boscone, 4

I-20094 CORSICO-MILANO

Tel: 0039 02 44 851

Fax: 0039 0245 101238

e-mail: Norton.edilizia@saint-gobain.com

Austria

Saint-Gobain Abrasives GmbH

Telsenberggasse 37,

A-5020 SALZBURG

Tel: 0043 662 43 00 76 77

Fax: 0043 662 43 01 75

e-mail: office@sga.net

Poland

Saint-Gobain Diamond Products Sp.zO.O.

AL. Krakowska 110/114

PL-00-971 WARSZAWA

Tel: 0048 22 868 29 36

Tel/Fax: 0048 22 868 29 27

e-mail: norton-diamond@wp.pl

Czech Republic

Norton Diamantove Nastroje Sro

Vinohradska 184

CS-13000 PRAHA 3

Tel: 0042 0267 13 20 21

Fax: 0042 0267 13 20 21

e-mail: norton.diamonds@komerce.cz**8 Appendix****8.1 Spare parts list**

POS	PAGE	CODE	DESIGNATION	TYPE (*)	REMARKS
1	EC01	00310006549	Basic Frame	S	
2	EC01	00310006550	Rear axle kit	S	
3	EC01	00310005495	Rear Wheel	W	
4	EC01	00310006551	Rear axle	S	
5	EC01	00310006552	Front wheel complete	W	
6	EC01	00310005502	Bushing Iglidur	W	
7	EC01	00310005129	Bushing Iglidur	W	
8	EC01	00310006553	Screw Feed. Spindle	S	
9	EC01	00310006554	Raise-lower screw	S	
10	EC01	00310004907	Bearing + Screw	W	
11	EC01	00310006555	Stop ring A20	S	
12	EC01	00310006556	Depth indicator cpl.	S	
13	EC01	00310004840	Hand wheel + nut	S	
14	EC01	00310004476	Handle	S	
15	EC01	00310002163	Hand wheel + Handle	S	
16	EC01	00310004190	Handle Grip 1/2"	S	
17	EC01	00310006557	Manoeuvring bar cpl.	S	
18	EC01	00310004177	Wrench 36mm	S	
19	EC01	00310004306	Wrench 30mm	S	
20	EC01	00310004229	Wrench 17mm	S	
21	EC01	00310006558	Support Water Tank	S	
22	EC01	00310003978	Connector for Hose	W	
23	EC01	00310004262	Water cock	W	
24	EC01	00310006559	Water tank cpl.	S	
25	EC01	00310006560	Stopper f. water tank	S	
26	EC02	00310006561	Blade shaft assy.	S	
27	EC02	00310004269	Nut 7/8" L. blade shaft	S	
28	EC02	00310006562	Loose collar 108	S	
29	EC02	00310006563	Bushing 2 blades	S	
30	EC02	00310005219	Inside collar 108	S	
31	EC02	00310004295	Bearing for blade shaft	W	
POS	PAGE	CODE	DESIGNATION	TYPE (*)	REMARKS


32	EC02	00310004506	Key for inside collar	S	
33	EC02	00310006564	Blade shaft assy.	S	
34	EC02	00310004835	Blade shaft pulley	S	
35	EC02	00310005200	Guide-a-cut cpl.	S	
36	EC02	00310046746	Blade guard 450 assy	S	
37	EC02	00310004181	Blade guard nut M16	S	
38	EC02	00310004255	Blade guard axle	S	
39	EC02	00310004233	Waterdistributor-Y	W	
40	EC02	00310004426	Water supply tape 1/2"	W	
41	EC02	00310004081	Hose coupling 1/2"	W	
42	EC02	00310006566	Blade splash guard	W	
43	EC02	00310006567	Motor frame	S	
44	EC02	00310006568	Axle motor frame cpl	S	
45	EC02	00310006569	Axle motor frame	S	
46	EC02	00310006570	Brake complete	S	
47	EC02	00310002336	Motor 1B30 Hatz	S	
48	EC02	00310005510	Motor pulley cpl.	S	
49	EC02	00310006572	Belt s XPZ 860 LW	W	
50	EC02	00310006574	Belt guard cpl.	S	
51	EC02	00310006577	Screw for motor	S	
58	EC02	00310002304	Motor stop switch	W	
59	EC02	00310002346	Water hose (set of 2)	W	
60	EC02	00310006886	Nipple 1/2"M-1/4"M	S	
61	EC01	00310004966	Nut hand wheel	S	
62	EC02	00310007048	Dover pin (set of 10)	S	

(*): S = Spare part, W = Wear part

Wear parts are worn out through normal use of the machine. The wear period depends a lot on the intensity of use of the machine. Wear parts must be serviced, used and eventually changed following the indications of the manufacturer. Any wear due to normal use of the machine will not be considered as a case of warranty. Genuine Clipper replacement parts should always be used.

8.2 Exploded part drawings

EC01



EC02

