




# IMPORTANT SAFETY NOTES




ALWAYS READ THE INSTRUCTIONS BEFORE USING PODIUM




NEVER USE A PODIUM WITH DAMAGED OR MISSING COMPONENTS




NEVER OVERREACH




NEVER HAVE MORE THAN ONE PERSON ON THE PLATFORM




NEVER USE ON UNEVEN OR SLOPING SURFACES




DO NOT MOVE PODIUM IF A PERSON IS STILL ON IT



NEVER USE BOXES FOR EXTRA HEIGHT, STAND ONLY ON THE PLATFORM




NEVER USE PODIUMS AS A MEANS OF ACCESS TO ANOTHER PLACE.



NEVER USE PODIUMS NEAR ELECTRICAL POWER LINES

BE AWARE OF THE FOLLOWING:-

- A. DO NOT USE ON LOOSE OR SLIPPERY SURFACES.
- B. NEVER STAND ON THE ACCESS LADDER TO WORK.
- C. WORKING PLATFORM MUST BE LEVEL.
- D. INSPECT BEFORE USE.
- E. ONLY ASCEND OR DESCEND THE LLWP USING THE ACCESS PROVIDED.
- F. FACE THE FOLDING BACK SECTION WHEN ASCENDING OR DESCENDING.
- G. ENSURE THE GATE IS CLOSED AND LOCKED BEFORE USE.
- H. BEWARE OF FINGER TRAPS.
- J. TO MOVE UNIT UNLOCK GATE AND DISMOUNT, UNLOCK CASTORS AND RE-LOCATE.
- K. IF IN DOUBT DO NOT GUESS CONSULT YOUR SUPPLIER.
- L. SEE OVERLEAF FOR COMPONENT CHECKLIST



ALWAYS LOCK ALL CASTORS WHEN PODIUM IS SITED, AND BEFORE USE.

# 750 AND PAS 250 750 PODIUM UNIT ASSEMBLY GUIDE



Dimensions — Platform at 0.50-0.75M x Width —0.65M x Depth 1.3M  
 Working Height— 2.75M (Max)  
 Dimensions — Folded Height —2.05M x Width - 0.25M x Depth - 1.3M  
 Weight— 31Kg Safe Working Load - 150kg  
 PAS 250— 35Kg(Mini Stabilisers)  
 Manufactured under an ISO9001:2008 Quality System  
 Complies fully with the Working at Height Regulations 2005 and PAS250 Specifications  
 Lightweight all Aluminium Construction



PSM PLANT & TOOL HIRE CENTRES LTD  
 020 8850 5658  
 info@psmhire.co.uk  
 www.psmhire.co.uk


# 750 AND PAS 750 PODIUM UNIT ASSEMBLY GUIDE



1 X FOLDING FRAME  
1 X PLATFORM  
1 X LADDER  
2 X STABILISER (FOR  
PAS 250 COMPLIANCE)



2) OPEN FRAME AND LOCK  
MECHANISM




3) FIT PLATFORM AT  
CORRECT HEIGHT



4) CLIP UPPER BRACE OF  
LADDER ABOVE RINGS ON  
VERTICALS WITH ASSEMBLED  
HOOKS AT TOP



5) POSITION UNIT AND  
LOCK CASTORS



6) FIT STABILISERS TO  
BACK VERTICALS ( FOR  
PAS 250 COMPLIANCE)



7) USE LADDER TO  
ACCESS PLATFORM



8) CLOSE AND  
LOCK GATE